FeiyuTech

G6Max Camera Compatibility List (Wi-Fi Control)

Brand	Camera Model	Control Form	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Sony	RX100 IV (RX100M4)	Wi-Fi	√	√	×	×	√	×	×	×	×	×	√	Any version	1.01	
	RX100 V (RX100M5)	Wi-Fi	√	√	×	×	√	×	×	×	×	×	√	Any version	1.01	
	RX100 VI (RX100M6)	Wi-Fi	√	√	×	√	√	√	×	×	×	×	√	Any version	1.01	
	RX100M5A	Wi-Fi	√	√	×	√	√	√	×	×	×	×	√	Any version	1.01	
	a 5100	Wi-Fi	√	√	√	×	√	×	×	×	×	×	√	Any version	1.01	
	a 6000	Wi-Fi	√	×	×	×	√	×	×	×	×	×	√	Any version	1.01	
	a 6100	Wi-Fi	√	√	×	√	√	√	×	×	×	×	√	Any version	1.01	
	a 6300	Wi-Fi	√	√	×	√	√	√	×	×	×	×	√	Any version	1.01	
	a 6400	Wi-Fi	√	√	×	√	√	√	×	×	×	×	√	Any version	1.01	
	a 6500	Wi-Fi	√	√	×	×	√	×	×	×	×	×	×	Any version	1.01	
	HDR-AS50	Wi-Fi	√	√	√	×	√	√	×	×	×	×	×	Any version	1.01	
	FDR-X3000R	Wi-Fi	√	√	√	×	√	√	×	×	×	×	×	Any version	1.01	
	ILCE-QX1	Wi-Fi	√	√	√	√	√	√	×	×	×	×	×	Any version	1.01	
	DSC-RX0	Wi-Fi	√	√	√	√	√	√	×	×	×	×	×	Any version	1.01	
	RX1R II	Wi-Fi	√	×	×	×	√	×	×	×	×	×	√	Any version	1.01	
	DSC-RX0G	Wi-Fi	√	√	×	×	√	×	×	×	×	×	√	Any version	1.01	
	DSC-RX0GG	Wi-Fi	√	√	×	√	√	×	×	×	×	×	√	Any version	1.12	

Brand	Camera Model	Control Form	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Canon	EOS M50	Wi-Fi	√	√	√	√	√	×	√	√	×	×	×	Any version	1.07	
	EOS 200D	Wi-Fi	√	√	√	√	√	×	√	√	×	×	×	Any version	1.01	
	EOS 200D Ⅱ (250D)	Wi-Fi	√	√	√	√	√	×	√	√	×	×	×	Any version	1.01	
	Powershot G7 X Mark Ⅲ	Wi-Fi	√	√	√	√	×	×	√	√	×	√	×	Any version	1.01	
	EOS RP	Wi-Fi	√	√	√	√	√	×	√	√	×	×	×	Any version	1.01	
	EOS M6 Mark Ⅱ	Wi-Fi	√	√	√	√	√	×	√	√	×	×	×	Any version	1.04	1. The GOMAX can start/ stop video recording only if the camera is turn on under video mode.

Brand	Camera Model	Control Form	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Panasonic	DMC-LX10	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	After connecting to WIFI for 30s, the camera will prompt: the monitoring screen is closed.
	DMC-LX100	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	
	DMC-GH4K	Wi-Fi	√	√	√	√	√	√	×	×	×	√	×	Any version	1.01	
	DC-GF9SGK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	
	DC-GX850K-K	Wi-Fi	√	√	√	√	√	√	×	×	×	√	×	Any version	1.01	
	DC-GF9SGK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	×	Any version	1.01	
	DC-GF10SGK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	×	Any version	1.01	
	DC-Z370GK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	
	DC-ZS220GK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	
	DMC-ZS110	Wi-Fi	√	√	√	√	√	√	×	×	×	√	√	Any version	1.01	
	DMC-GX85GK	Wi-Fi	√	√	√	√	√	√	×	×	×	√	×	Any version	1.01	

Brand	Camera Model	Control Form	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
GoPro	HERO5/6	Wi-Fi	√	√	√	×	×	×	×	×	×	×	×	Any version	1.01	
	HERO7 Black	Wi-Fi	√	√	√	×	×	√	×	×	×	×	×	Any version	1.01	
	HERO7 Silver/White	Wi-Fi	√	√	—	—	—	—	—	—	×	×	×	Any version	1.01	
	HERO8	Wi-Fi	√	√	√	—	—	—	—	—	×	×	×	Any version	1.01	For the way to connect HERO8, see G6 Connecting HERO8 tutorial
SJcam	SJ6 LEGEND	Wi-Fi	×	—	—	—	—	—	—	—	×	×	×	Any version	1.01	
Xiaoyi	Yi 4K	Wi-Fi	√	√	×	—	—	—	—	—	×	×	×	Any version	1.01	
FeiYu	KICCA	Wi-Fi	√	√	—	—	—	—	—	—	—	—	—	Any version	1.01	

Notice:
1. "√" Means Support this function, "×" Means Do not Support;

G6Max Camera Compatibility (Cable Control)

Brand	Camera Model	Cable	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Sony	RX100 III (RX100M3)	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	2.00	1.01	1. After connecting the cable, be sure to power on the GOMAX before the camera. 2. Support Optical Zoom; Please set [Zoom Setting] to be "CleanImage Zoom" or "Digital Zoom" to enable Digital Zoom. 3. Please set [Auto Review] to be "OFF" when shooting the timelapse video;
	RX100 IV (RX100M4)	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.30	1.01	
	RX100M5A	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	2.00	1.01	
	RX100 VI (RX100M6)	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	RX100 VII (RX100M7)	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	ZV-1	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	ZV-E10	Type-C to Type-C (CO2)	√	√	√	×	×	×	×	×	×	×	×	1.00	1.07	1. Please set the [Ctrl w/ Smartphone] to be off. [Network] → [Ctrl w/ Smartphone] → [OFF] 2.Set "USB Connecting" to be "PC Remote" [Network] → [PC Remote Function] →[PC Remote]→[Ok] 3. Set"Still Img. Save Dest." to be "Camera Only" [Network] → [PC Remote Function] →[Still Img. Save Dest.]→ Camera Only] 4. Please set [Auto Review] to be"OFF" when shooting the timelapse video; 5.After connecting the cable, be sure to power on the GOMAX before the camera. 6.The camera icon on the global screen lights up after a successful connection. And the screen of the camera displays the shooting mode. 7.When the camera is in photo mode, you can switch between photo and video modes from gimbal; when the camera is in video mode, the gimbal can only control recording video.
	DSC-RX0	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	DSC-RX0GG	Type-C to Multi	√	√	√	×	×	×	×	×	×	×	√	1.00	1.12	
	a 6100	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	a 6300	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	2.00	1.01	1. After connecting the cable, be sure to power on the GOMAX before the camera. 2. Support Optical Zoom; Please set [Zoom Setting] to be "CleanImage Zoom" or "Digital Zoom" to enable Digital Zoom. 3. Please set [Auto Review] to be "OFF" when shooting the timelapse video;
	a 6400	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.01	
	a 6500	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	2.00	1.01	
	a 6600	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	2.00	1.04	
	DSC-RX0	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	3.00	1.01	1. After connecting the cable, be sure to power on the GOMAX before the camera. 2. Support Optical Zoom; Please set [Zoom Setting] to be "CleanImage Zoom" or "Digital Zoom" to enable Digital Zoom. 3. Please set [Auto Review] to be "OFF" when shooting the timelapse video;
	DSC-RX0 Ⅱ	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.00	1.04	
	A7C	Type-C to Type-C (CO2)	√	√	√	×	×	×	×	×	√	×	×	1.00	1.06	1. After connecting the cable, be sure to power on the GOMAX before the camera. 2. Please set the [Ctrl w/ Smartphone] to be off. [Network] → [Ctrl w/ Smartphone] → [OFF] 3.Set "USB Connecting" to be "PC Remote". [Network] → [PC Remote Function] →[PC Remote]→[Ok] 4. Set "Still Img. Save Dest." to be "Camera Only". [Network] → [PC Remote Function] →[Still Img. Save Dest.]→ [Camera Only] 5. Please set [Auto Review] to be"OFF" when shooting the timelapse video; 6. Support Switch Photo/ Video Mode in P, A, S, M, AUTO Mode.
	A7M4	Type-C to Multi	√	√	√	×	×	×	×	×	√	×	√	1.01	1.07	1.After connecting the cable, be sure to power on the global before the camera. 2.Operate digital zoom,the camera's digital zoom function needs to be turned on. 3.Please set [Auto Review] to be "OFF" when shooting the timelapse video

Brand	Camera Model	Cable	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Canon	EOS M50	Type-C to Micro (AE0)	√	√	√	×	×	×	×	×	×	×	×	1.0.0	1.02	1.After connecting the cable, be sure to power on the GOMAX before the camera and wait for about 5 seconds for successfully connection after camera power on, the camera icon on the global screen will light up.
	EOS M50 Mark Ⅱ	Type-C to Micro (AE0)	√	√	√	×	×	×	×	×	×	√	×	1.0.0	1.06	
	EOS RP	Type-C to Type-C (CO2)	√	√	√	×	×	×	×	×	×	√	×	1.3.0	1.02	1. GOMAX can switch to video mode from P,A shooting mode, but need to switch to video mode from photo mode on camera manually. 2. Switch to "M" Mode on the lens when use pull focus. 3. Please do not use the release cable to control the video recording while in photo mode camera as it is easy to cause the camera crash. 4. When shooting timelapse video, please set the Canon camera "Image Review" to be off. 5. It shows that using the adapter with the EF Mount Lens will increase the delay of pull focus.
	EOS M6 Mark Ⅱ	Type-C to Type-C (CO2)	√	√	√	×	×	×	×	×	×	√	×	1.0.0	1.02	1. GOMAX can switch to video mode from P,A,M shooting mode, but need to switch to video mode from photo mode on camera manually. 2. Switch to "M" Mode on the lens when use pull focus. 3. When shooting timelapse video, please set the Canon camera "Image Review" to be off
	EOS M6	Type-C to TRS2.5 (TS2)	√	×	×	×	×	×	×	×	√	×	×	1.0.0	1.02	
	EOS 200D Ⅱ (250D)	Type-C to Micro (AE0)	√	√	√	×	×	×	×	×	×	√	×	1.0.0	1.04	1. Please switch photo / video mode on camera manually. 2. Switch to "M" Mode on the lens when use pull focus. 3. When shooting timelapse video, please set the Canon camera "Image Review" to be off.
	Powershot G7 X Mark Ⅲ	Type-C to Type-C (CO2)	√	√	×	×	×	×	×	×	×	√	×	1.0.1	1.02	
	EOS R6	Type-C to Type-C (CO2)	√	√	×	×	×	×	×	×	×	×	×	1.4.0	1.07	1. Please switch photo / video mode on camera manually.
	EOS R10	Type-C to Type-C (CO2)	√	√	×	×	×	×	×	×	×	×	×	1.0.1	1.07	

Brand	Camera Model	Cable	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Panasonic	DC-S5GK-K	Type-C to DC2.5mm	√	√	×	×	×	×	×	×	√	×	×	2.00	1.02	1. Please switch photo / video mode on camera manually.
		Type-C to Type-C (CO2)	√	√	×	×	×	×	×	×	×	×	×	2.00	1.02	2. GOMAX can switch photo/ video mode in P, A, S, M shooting mode. 3. The camera will auto focus when control capture photo.
	DMC-GH6GK	Type-C to DC2.5mm	√	√	×	×	×	×	×	×	√	×	×	2.7	1.01	1. Please switch photo / video mode on camera manually.

Brand	Camera Model	Cable	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Fujifilm	X-T20	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	2.01	1.02	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X-T30	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	1.20	1.02	
	X-T100	Type-C to TRS2.5 (TS2)	√	×	×	×	×	×	×	×	√	×	×	2.00	1.02	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X-T200	Type-C to TRS3.5 (TS3) Optional	√	√	×	×	×	×	×	×	√	×	×	1.00	1.02	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X-A5	Type-C to TRS2.5 (TS2)	√	×	×	×	×	×	×	×	√	×	×	2.00	1.02	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X-A7	Type-C to TRS2.5 (TS2)	√	×	×	×	×	×	×	×	√	×	×	1.30	1.02	
	X-T3	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	3.01	1.02	
	X-T4	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	1.00	1.02	
	X-H1	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	2.01	1.02	
	X-S10	Type-C to TRS3.5 (TS3) Optional	√	√	×	×	×	×	×	×	√	×	×	1.00	1.02	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X-E3	Type-C to TRS2.5 (TS2)	√	√	×	×	×	×	×	×	√	×	×	1.22	1.07	
	X-T30 II	Type-C to TRS2.5(TS2)	√	√	×	×	×	×	×	×	√	×	×	1.00	1.07	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	X100V	Type-C to TRS2.5(TS2)	√	√	×	×	×	×	×	×	√	×	×	2.00	1.07	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.

Brand	Camera Model	Cable	Capture Photo	Start/ Stop Recording Video	Switch Photo/ Video Mode	ISO Adjustment	EV Adjustment	WB Adjustment	Aperture Adjustment	Shutter Speed Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Version	HEB Version Info.	Remark
Nikon	Z50	Type-C to micro (AE0)	√	√	×	×	×	×	×	×	×	×	×	1.02	1.06	1. Please set [REC/REMOTE RELEASE] to be [REMOTE] under the [MOVIE SETTING] menu 2. Please switch photo / video mode on camera manually.
	Z7	TypeC to TypeC (CO2)	√	√	×	×	×	×	×	×	×	×	×	3.31	1.07	1. After connecting the cable, be sure to power on the Feiyu gimbal before the camera and wait for about 6 seconds for successfully connection after camera power on 2. Please switch photo / video mode on camera manually.
	Z7 II	TypeC to TypeC (CO2)	√	√	×	×	×	×	×	×	×	×	×	1.00	1.07	1. After connecting the cable, be sure to power on the Feiyu gimbal before the camera and wait for about 6 seconds for successfully connection after camera power on 2. Please switch photo / video mode on camera manually.
	Z fc	Type-C to Type-C (CO2)	√	√	×	×	×	×	×	×	×	×	×	1.10	1.07	1. After connecting the cable, be sure to power on the Feiyu gimbal before the camera and wait for about 6 seconds for successfully connection after camera power on 2. Please switch photo / video mode on camera manually.

Notice:
1. "√" Means Support this function, "×" Means Do not Support;
2. For the Sony Camera with Multi Port, can use Type-C to Multi release cable to control Sony camera but not charge; Use Type-C to Micro (AE0)release cable can charge Sony camera but not control it;