

product		AK4000&AK2000													
		WIFI	Lens	Photo	Video	Follow Focus	Zoom	IOS	EXP	WB	Switch Mode	Keyboard Firmware needed	Keyboard Firmware needed	Note	
camera brand	camera type														
SONY	α9	Yes	12-44G	OK	OK	NO	NO	OK	NO	OK	NO	ak4000_ajb_sony_v1.1.1 or later			
	α7 III	Yes	16-50	OK	OK	NO	OK	OK	NO	OK	NO	ak4000_ajb_sony_v1.1.1 or later		test with Sony 16-50 and 24-70 GM lenes, cant zoom	
	α7R III	Yes	16-50	OK	OK	NO	NO	OK	OK	OK	NO	ak4000_ajb_sony_v1.1.1 or later			
	α7S II	Yes	16-50	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later			
	α7R II	Yes	24-70	OK	OK	NO	NO	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later			
	α7S	Yes	16-35	OK	OK	NO	NO	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later			
	α7R	Yes	16-35	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later			
	RX0	Yes	NA	OK	OK	OK	NO	OK	OK	OK	OK	ak4000_ajb_sony_v1.1.1 or later	Ver. 1.1.1		
	RX100 V	Yes	F1,8	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later	Ver. 1.0.2		
	RX100 IV	Yes	2.8-4.5	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.1.1 or later	Ver. 1.0.0		
	RX100 VI	Yes	2.8-4.5	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.1.1 or later			
	α5100	Yes	16-50	OK	OK	NO	OK	NO	OK	NO	OK	ak4000_ajb_sony_v1.1.1 or later			
	α6000	Yes	16-50	OK	NO	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later		Can't control the recording due to the protocol	
	α6500	Yes	28-70	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.1.1 or later			
	α6300	Yes	28-70	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.1.1 or later			
			16-50	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.1.1 or later			
	FDR-X3000R	Yes	NA	OK	OK	NO	NO	NO	OK	OK	OK	ak4000_ajb_sony_v1.1.1 or later			
	HDR-AS50R	Yes	NA	OK	OK	NO	NO	NO	OK	OK	OK	ak4000_ajb_sony_v1.1.1 or later			
	QX1	Yes	20	OK	OK	NO	OK	OK	OK	OK	OK	ak4000_ajb_sony_v1.1.1 or later			
	α7 II	Yes	FE 4/16-35	OK	OK	NO	NO	NO	OK	NO	NO	ak4000_ajb_sony_v1.2.0 or later			
	α7	Yes	FE 4/16-35	OK	NO	NO	NO	NO	OK	NO	NO	ak4000_ajb_sony_v1.2.0 or later		a7 does not support recording when wifi is connected	
	RX1RII	Yes		OK	NO	NO	OK	NO	NO	NO	NO	ak4000_ajb_sony_v1.2.0 or later			
	WX500	Yes	3.5-6.4	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.2.1 or later	Ver. 1.00		
HX90	Yes	3.5-6.4	OK	OK	NO	OK	NO	OK	NO	NO	ak4000_ajb_sony_v1.2.1 or later	Ver. 1.00			
RX100M5A	Yes	F1,8	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.2.1 or later	Ver. 1.00			
α6400	Yes	28-70	OK	OK	NO	NO	OK	OK	OK	NO	ak4000_ajb_sony_v1.2.5 or later	Camera firmware Version:1.0.0			
		16-50	OK	OK	NO	OK	OK	OK	OK	NO	ak4000_ajb_sony_v1.2.5 or later	Camera firmware Version:1.0.0			

product		AK4000&AK2000													
		WIFI	Lens	Photo	Video	Follow Focus	Zoom	IOS	EXP	WB	Switch Mode	Keyboard Firmware needed	Keyboard Firmware needed	Note	
camera brand	camera type														
Canon	EOS 80D	Yes		OK	OK	OK	NO	OK	OK	OK	OK	ak4000_ajb_canon_v1.1.0 or later			
	EOS 6D Mark II	Yes	24-70	OK	OK	OK	NO	OK	OK	OK	OK	ak4000_ajb_canon_v1.1.0 or later			
	EOS 6D	Yes		OK	NO	OK	NO	OK	OK	OK	OK	ak4000_ajb_canon_v1.1.0 or later		Camera does not support recording when wifi is connected	
	EOS 200D	Yes	18-55	OK	OK	OK	NO	OK	OK	OK	OK	ak4000_ajb_canon_v1.1.0 or later			
	EOS 5D Mark IV	Yes	24-105 24-70	OK	OK	OK	NO	OK	OK	OK	OK	ak4000_ajb_canon_v1.1.0 or later			
	M50	Yes		OK	OK	NO	NO	NO	NO	NO	OK	ak4000_ajb_canon_v1.1.0 or later			
	EOS-70D	Yes	16-35mm f/2.8L II USM	OK	NO	NO	NO	OK	OK	NO	NO	ak4000_ajb_canon_v1.2.1 or later	Ver. 1.1.1		
	EOS-R	Yes	24-70mm f/2.8L USM	OK	OK	NO	NO	OK	OK	NO	NO	ak4000_ajb_canon_v1.2.1 or later	Ver. 1.0.2		
	EOS-77D	Yes	24-70mm f/2.8L USM	OK	OK	OK	NO	OK	OK	NO	OK	ak4000_ajb_canon_v1.2.1 or later	Ver. 1.0.0		

product		AK4000&AK2000													
		WIFI	Lens	Photo	Video	Follow Focus	Zoom	IOS	EXP	WB	Switch Mode	Keyboard Firmware needed	FM of the camera		
camera brand	camera type														
Panasonic	DMC-LX100	Yes	24-150	OK	OK	OK	OK	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.1 or later			
	DMC-LX10	Yes		OK	OK	OK	OK	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.2 or later			
	DC-ZS70GK	Yes		OK	OK	OK	OK	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.3 or later			
	DC-ZS220GK	Yes	24-360	OK	OK	OK	OK	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.4 or later			
	DMC-GH4	Yes	25mm F1.4	OK	OK	OK	NO	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.5 or later			
	DC-GF9XGK	Yes	12-32	OK	OK	OK	OK	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.6 or later			
	DC-GF9KGK	Yes	12-32	OK	OK	OK	NO	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.7 or later			
	DC-GH5SGK-K	Yes	25mm F1.4	OK	OK	OK	NO	OK	OK	OK	NA	Bluetooth firmware V1.07 or later and ak4000_ajb_panasonic_v1.1.10 or later			
			35-100	OK	OK	OK	NO	OK	OK	OK	NA				
	DC-GX9KGK-K	Yes	12-32	OK	OK	OK	NO	OK	OK	OK	NA	Bluetooth firmware V1.07 or later and ak4000_ajb_panasonic_v1.1.10 or later			
	DC-GF10KGK	Yes	12-32	OK	OK	OK	NO	OK	OK	OK	NA	ak4000_ajb_panasonic_v1.1.10 or later			
	DMC-ZS110	Yes	Manual Exposure Mode(25-250)	OK	OK	OK	OK	OK	NO	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Shutter-Priority AE Mode(25-250)	OK	OK	OK	OK	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Aperture-Priority AE Mode(25-250)	OK	OK	OK	OK	OK	OK	OK		aak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Programme AE Mode(25-250)	OK	OK	OK	OK	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
	DMC-GX85	Yes	Manual Exposure Mode (20 mm/f1.7 II ASPH.)	OK	OK	OK	NO	OK	NO	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Shutter-Priority AE Mode (20 mm/f1.7 II ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Aperture-Priority AE Mode (20 mm/f1.7 II ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
		Yes	Programme AE Mode (20 mm/f1.7 II ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.1.2		
	GH5	Yes	Manual Exposure Mode (12-35mm, F2.8 ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.2.3		
Yes		Shutter-Priority AE Mode (12-35mm, F2.8 ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.2.3			
Yes		Aperture-Priority AE Mode (12-35mm, F2.8 ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.2.3			
Yes		Programme AE Mode (12-35mm, F2.8 ASPH.)	OK	OK	OK	NO	OK	OK	OK		ak4000_ajb_panasonic_v1.2.4 or later	Ver.2.3			