

Qing Camera CompatibilityList (Cable Control)						
Brand	Camera list	Camera version	Control cable	Function	Setting notes on Camera/Lens	HUB Firmware
Canon	5D MarkIV	1.1.2	USB 3.0 to Micro 3.0 (A02)	1. Take photos 2. Start/Stop recording video 3. Follow focus electronically	When using Follow focus electronically, the lens needs to be in AF mode	RT_HUB_V101
	EOS 90D	1.0.0	USB 2.0 to micro (A01)			
	EOS 200D II	1.0.0				
	80D	1.0.2	USB 2.0 to mini (B01)			
	6D	1.1.8				
	5D MarkIII	1.3.5				
	6D MarkII	1.0.3	USB 2.0 to Type C (C01)		Please turn off the WIFI connection for Cable control	
	EOS R	1.0.0				
	EOS RP	1.3.0				
	G7X mark III	1.0.1			When using Follow focus electronically, the lens needs to be in AF mode	
	M6mark2	1.1.0				
	EOS R5	1.1.1				
EOS R6	1.1.1					
Sony	α6300	V2.00	Type-C to Multi	1. Take photos 2. Start/Stop recording video 3. Zoom/Half-press to focus	...	RT_HUB_V101
	α7SII	V2.00				
	α7RII	V4.00				
	α7II	V4.00				
	α9	V2.00				
	α7R	V2.00				
	α6400	V1.00				
	α7 III (A7M3)	V3.00				
	α7R III	V3.01				
	α7R IV	V1.00				
	6100	V1.00				
	6600	V1.00				
	α6500	V2.00				
Nikon	D7500	1.00	USB 2.0 to Micro (A01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electronically	1. After turning on the camera, it takes a few seconds for the camera to connect successfully 2. Make sure the camera live view function is on when using the gimbal control function (LV) 3. To control recording you need to turn the camera to video mode . 4. When using Follow focus electronically the lens needs to be in AF mode and very slow 5.The camera only has the light indicator and the screen does not display the	RT_HUB_V101
	Z7	1.00	USB 2.0 to Type C (C01)		1. After turning on the camera, it takes a few seconds for the camera to connect successfully 2. Make sure the camera live view function is on when using the gimbal control function (LV) 3. To control recording you need to turn the camera to video mode .	
	Z6	2.00			4. When using Follow focus electronically the lens needs to be in AF mode and very slow	
	D850	1.01	USB 3.0 to Micro 3.0 (A02)			
Panasonic	GH5s	V1.2	USB 2.0 to Type C (C01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electronically	1. USB mode choose PC(Tether) 2. WIFI and USB cable control cannot be used simultaneously 3. When using Follow focus electronically, the lens needs to be in AF mode	RT_HUB_V101
	GH4	V2.7	Panasonic Shutter Cable Type C to DC2.5		To control recording you need to turn the camera to video mode .	
	LUMIX G9	V2.0				
	S1H	V2.0			1. Take photos 2. Start/Stop recording video	
FUJIFILM	XT-200	V1.02	Type-C to TRS3.5 (T03)	1. Take photos 2. Start/Stop recording video 3. Half-press to focus	1. Please set up "MIC/REMOTEO RELEASE "to REMOTE. Steps: Press Menu, Video Setting) MIC/REMOTEO RELEASE) REMOTE 2. To control recording you need to turn the camera to video mode .	RT_HUB_V101
	XS-10	V1.02			1. Please set up "MIC/REMOTEO RELEASE "to REMOTE. Steps: Press Menu, Video Setting) MIC/REMOTEO RELEASE) REMOTE 2. To control recording you need to turn the camera to video mode . 3.Take photo,you need to turn the camera to Photo mode	