Updating Time: 23rd Jan., 2026 Sac. Version: 1.0.0

Feiyu SCORP-2 Camera Compatibility (Bluetooth Control)

Brand	Camera Model	Bluetooth	Remote Photo	Remote Video	Focus	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	On/Long Press to Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Sony	ZV-E10 V1.00(02)-02	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V102	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	ZV-1M2	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	
	ZV-1F	Bluetooth	√	√	√	×	√	×	√	√	×	2.00	Bluetooth_V100	
	ZV-1G	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	
	DT-7M	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually. 4.Due to limitations of some camera systems, camera control cannot be achieved in only Bluetooth pairing state. You must also enter the Bluetooth camera control in advance. 5.Since the Bluetooth shutter has a higher priority,if adjust camera parameters such as aperture,shutter,ISO by connecting with remote release cable,Please make sure bluetooth is disconnected
	DSC-RX0M2G	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	
	DSC-RX100M7	Bluetooth	√	√	√	×	√	×	√	√	×	2.00	Bluetooth_V100	
	ZV-E10	Bluetooth	√	√	√	×	√	×	√	√	×	2.00	Bluetooth_V102	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	ILME-FX3	Bluetooth	√	√	√	×	√	×	√	√	×	1.01	Bluetooth_V102	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	ZV-1II	Bluetooth	√	√	√	×	√	×	√	√	×	4.01	Bluetooth_V102	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	ZV-E1	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Sac Dis→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Due to limitations of some camera systems, camera control cannot be achieved in only Bluetooth pairing state. You must also enter the Bluetooth camera control in advance. 4.Since the Bluetooth shutter has a higher priority,if adjust camera parameters such as aperture,shutter,ISO by connecting with remote release cable,Please make sure bluetooth is disconnected 5.Please watch photo / video mode on camera manually.
	DSC	Bluetooth	√	√	√	×	√	×	√	√	×	2.10	Bluetooth_V107	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	Cinema Line FX3(ILME-FX3)(V2)	Bluetooth	√	√	√	×	√	×	√	√	×	2.00	Bluetooth_V107	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing
	ZV-E1(V2)	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V107	1.Key to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Bluetooth Settings→Pairing 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.

Brand	Camera Model	Bluetooth	Remote Photo	Remote Video	Focus	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	On/Long Press to Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Canon	EOS 2000D(V)	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.3	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Remote 2.Wireless communication setting→Bluetooth function→Pairing "Pairing" is grey, please click "Bluetooth connection info" Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon → Switch to video 6.Click tool icon →Power saving→Auto power off→Off 7.Please watch photo / video mode on camera manually.
	EOS 90D	Bluetooth	√	√	√	×	√	×	√	√	×	1.1.0	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Remote 2.Wireless communication setting→Bluetooth function→Pairing "Pairing" is grey, please click "Bluetooth connection info" Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec / Left/right 2 sec 5.Switching the camera to video mode:BC-Click camera icon → Switch to video 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	Bluetooth_V102	1.Wireless communication setting→Bluetooth function→Remote 2.Wireless communication setting→Bluetooth function→Pairing "Pairing" is grey, please click "Bluetooth connection info" Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec / Left/right 2 sec 5.Switching the camera to video mode:BC-Click camera icon →Remote control 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R6	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.2	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→ 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R7	Bluetooth	√	√	√	×	√	×	√	√	×	1.3.1	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode:Click camera icon→Click mode→Left/right 22 sec/remote or Left/right 2sec/remote 5.Switching the camera to video mode:Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R50	Bluetooth	√	√	√	×	√	×	√	√	×	1.2.0	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Click camera icon → Switching the camera to video mode:Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R62	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	Bluetooth_V104	1.Click wireless menu→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→ Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Tool icon→Power saving→Auto power off→Disable 5.Please watch photo / video mode on camera manually.
	EOS R6 II	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0.1	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon → Switch to video 6.Click tool icon →Power saving→Auto power off 7.Please make sure turn the global on with Photo mode
	EOS 90D Mark II	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.1	Bluetooth_V104	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→ 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode:Sharing setting→Mode→Left/right 22 sec/remote or Left/right 2sec/remote 5.Switching the camera to video mode:Sharing setting→Remote control→Enable 6.Function setting→Power saving→Auto power off 7.Please watch photo / video mode on camera manually.
	EOS RP	Bluetooth	√	√	√	×	√	×	√	√	×	1.4.0	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Remote 2.Wireless communication setting→Bluetooth function→Pairing "Pairing" is grey, please click "Bluetooth connection info" Scroll to other Bluetooth connection, then pairing again. 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:Click camera icon→Remote control→Enable 6.Click tool icon →Power saving→Auto power off 7.Please watch photo / video mode on camera manually.
	PowerShot G7 X Mark III	Bluetooth	√	√	√	×	√	×	√	√	×	1.3.0	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Click camera icon→ Left/right 22 sec/remote or Left/right 2 sec 5.Switching the camera to video mode: →Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R6 Mark II	Bluetooth	√	√	√	×	√	×	√	√	×	1.1.1	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Click camera icon→ Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon→Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R8	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon → Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R50V	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	Bluetooth_V108	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon → Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	EOS R6 Mark II	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	Bluetooth_V107	1.Wireless communication setting→Bluetooth function→Enable 2.Wireless communication setting→Wi-Fi/Bluetooth connection→Scroll to Wireless Remote→Add a device to connect to 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to B-mode(photo mode):Single tap the SET button→Click mode→Left/right 22 sec/remote or Left/right 2 sec/remote 5.Switching the camera to video mode:BC-Click camera icon → Remote control→Enable 6.Click tool icon →Power saving→Auto power off→Disable 7.Please watch photo / video mode on camera manually.
	PowerShot V10	Bluetooth	√	√	√	×	√	×	√	√	×	1.0.0	V1.27	1.Turn the camera on→Menu→Connect to Wireless Remote→Add a device to connect to 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.When the camera shows that it has been paired with "SCORP-2"，please press the shutter button to exit, or press menu to exit

Brand	Camera Model	Bluetooth	Remote Photo	Remote Video	Focus	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	On/Long Press to Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Nikon	Z50	Bluetooth	√	√	√	×	√	×	√	√	×	1.10	Bluetooth_V104	1.Click tool icon→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	Z30	Bluetooth	√	√	√	×	√	×	√	√	×	2.00	Bluetooth_V100	1.Setup Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	Z 6_	Bluetooth	√	√	√	×	√	×	√	√	×	1.10	Bluetooth_V100	1.Network Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	Z 7_	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V100	1.Setup Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.
	Z6II	Bluetooth	√	√	√	×	√	×	√	√	×	1.02	Bluetooth_V107	1.Bluetooth has not been paired: Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Bluetooth has been paired: Setup Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 3.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Tool icon→Power saving→Time:5S lock→Power off delay→Standby time→Disabled 5.Bluetooth disconnected by camera standby, please single tap the shutter button on camera to wake up.
	Z50II	Bluetooth	√	√	√	×	√	×	√	√	×	1.00	Bluetooth_V107	1.Setup Menu→Wireless remote(BL-5)→ option→Wireless remote control→On 2.Camera operation: Exit left from the main interface → Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please watch photo / video mode on camera manually.

Notice:
"√" Means Support this function, "×" Means Do not Support.