Feiyu SCORP-Mini2 Camera Compatibility （Bluetooth Control）

Brand	Camera Model	Bluetooth	Gesture Photo	Start/ Stop Recording Video	Playback	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Sony	RX100M7	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	1.How to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Rmt Ctrl→On Network→PC Remote Settings→Pairing 2.Normal operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please switch photo / video mode on camera manually.
Sony	ZV-1	Bluetooth	√	√	√	×	×	×	√	×	×	3.01	V1.04	
Sony	ZV-1M2	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	ZV-E1	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	A7C	Bluetooth	√	√	√	×	×	×	√	×	×	3.00	V1.04	1.How to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Rmt Ctrl→On Network→PC Remote Settings→Pairing 2.Normal operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Due to limitations of some camera systems, camera control cannot be activated in only Bluetooth pairing state. You must also ensure that the Bluetooth remote control is on. 4.Since the Bluetooth protocol has a higher priority,if adjust camera parameters such as aperture shutter ISO by connecting with shutter cable, the APP interface will not be synchronized. 5.Please switch photo / video mode on camera manually.
Sony	A6400	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	A6600	Bluetooth	√	√	√	×	×	×	√	×	×	2.00	V1.04	
Sony	A6700	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	A7CII（A7CM2）	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	A7RM5	Bluetooth	√	√	√	×	×	×	√	×	×	2.00	V1.04	
Sony	A7RIVA（A7RM4）	Bluetooth	√	√	√	×	×	×	√	×	×	1.30	V1.04	
Sony	A7 RIIIA（A7M3）	Bluetooth	√	√	√	×	×	×	√	×	×	1.00	V1.04	
Sony	ZV-E10	Bluetooth	√	√	√	×	×	×	√	×	×	3.00	V1.04	1.How to set up the camera's bluetooth: MENU→Network→Bluetooth Settings→Bluetooth Function→On Network→Bluetooth Rmt Ctrl→On Network→PC Remote Settings→Pairing 2.Normal operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please switch photo / video mode on camera manually.

Brand	Camera Model	Bluetooth	Gesture Photo	Start/ Stop Recording Video	Playback	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Canon	EOS R6II	Bluetooth	√	√	√	×	×	×	√	×	×	1.1.0	V1.04	1.Wireless communication settings→Bluetooth function→Remote 2.Wireless communication settings→Bluetooth function→Pairing / If the camera has been paired before, please select "Delete pairing info" below to clear Bluetooth connection, then pairing again.) 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(photo mode) Single tap the QCSET button→Menu→Wireless communication settings→Bluetooth remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→Disable 5.Please switch photo / video mode on camera manually.
Canon	EOS R50	Bluetooth	√	√	√	×	×	×	√	×	×	1.0.0	V1.04	1.Wireless communication settings→Enable 2.Wireless communication settings→Bluetooth→Remote→Pairing Mode→Add a device to connect 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Power saving→Auto power off→Disable 5.Please switch photo / video mode on camera manually.
Canon	EOS R	Bluetooth	√	√	√	×	×	×	√	×	×	1.8.0	V1.04	1.Wireless communication settings→Bluetooth function→Remote 2.Wireless communication settings→Bluetooth function→Pairing / If the camera has been paired before, please select "Delete pairing info" below to clear Bluetooth connection, then pairing again.) 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(photo mode) Single tap the QCSET button→Menu→Wireless communication settings→Bluetooth remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→Disable 5.Please switch photo / video mode on camera manually.
Canon	EOS 200D II	Bluetooth	√	√	√	×	×	√	×	×	1.0.3	V1.04	1.Wireless communication settings→Bluetooth function→Remote 2.Wireless communication settings→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→Add a device to connect to 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(photo mode) Single tap the QCSET button→C0 low mode→Dial:1-time:1S secs/remote or Dial:1-time:2 secs/remote 5.Switching the camera to video mode(M) Remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→OFF 6.Please switch photo / video mode on camera manually.
Canon	EOS R8	Bluetooth	√	√	√	×	×	√	×	×	1.0.0	V1.04	1.Wireless communication settings→Bluetooth settings→Enable 2.Wireless communication settings→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→Add a device to connect to 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(photo mode) Single tap the Q button→C0 low mode→Dial:1-time:1S secs/remote or Dial:1-time:2 secs/remote 5.Switching the camera to video mode(M) Remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→Disable 6.Please switch photo / video mode on camera manually.
Canon	EOS R7	Bluetooth	√	√	√	×	×	√	×	×	1.3.1	V1.04	1.Wireless communication settings→Bluetooth settings→Enable 2.Wireless communication settings→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→Add a device to connect to 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode Q →C0 low mode→Dial:1-time:1S secs/remote or Dial:1-time:2secs/remote 5.Switching the camera to video mode(M) Remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→Disable 6.Please switch photo / video mode on camera manually.
Canon	EOS R10	Bluetooth	√	√	√	×	×	√	×	×	1.0.0	V1.04	1.Wireless communication settings→Bluetooth settings→Enable 2.Wireless communication settings→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→Add a device to connect to 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(Shooting settings→C0 low mode→Dial:1-time:1S secs/remote or Dial:1-time:2secs/remote 5.Switching the camera to video mode(M) Remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off→Disable 6.Please switch photo / video mode on camera manually.
Canon	EOS R50 Mark II	Bluetooth	√	√	√	×	×	√	×	×	1.0.1	V1.05	1.Wireless settings→Bluetooth settings→Enable 2.Wireless settings→Wi-Fi/Bluetooth connection→Connect to Wireless Remote→Add a device to connect to 3.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 4.Switching the camera to M mode(Shooting settings→C0 low mode→Dial:1-time:1S secs/remote or Dial:1-time:2secs/remote 5.Switching the camera to video mode(M) Remote control→Enable→Shutter button→Press halfway: Focus→Enable→Power saving→Auto power off 6.Please switch photo / video mode on camera manually.

Brand	Camera Model	Bluetooth	Gesture Photo	Start/ Stop Recording Video	Playback	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
Nikon	Z30	Bluetooth	√	√	√	×	×	×	√	×	×	1.10	V1.04	1.Wireless remote(M-UP) options→Wireless remote control→On 2.Global operation: Swipe left from the main interface →Bluetooth setting→Turn on camera control button→Click the camera name to pairing 3.Please switch photo / video mode on camera manually.

Brand	Camera Model	Bluetooth	Gesture Photo	Start/ Stop Recording Video	Playback	Shutter Speed Adjustment	Aperture Adjustment	ISO Adjustment	Halfway Press To Focus	Pull Focus	Digital Zoom Control	Camera Firmware Version	Bluetooth Firmware Version	Remark
GoPro	GoPro8	Bluetooth	√	√	√	×	×	×	√	×	×	02.40	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on,please make sure the GoPro is recording mode, then turn the GoPro on, swipe down from homepage to find "Preferences", tap "Connections", click "Connect Device" next, tap "GoPro App". 2.After turn the global on, swipe left to find "More" next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep. 3.Finally, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro9	Bluetooth	√	√	√	×	×	×	√	×	×	02.01	1.50	1.How to active the Bluetooth for GoPro: Turn the camera on, please make sure the GoPro is taking picture mode,swipe down from homepage to find "Preferences", tap "Connections", click "Connect Device" next, then turn the global on, swipe left to find "More", click next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep. 2.Finally, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 3.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro7 SILVER	Bluetooth	√	√	√	×	×	×	√	×	×	02.00	1.04	1.How to active the Bluetooth for GoPro: Turn the GoPro on, swipt down from homepage to find "Preferences", tap "Connections", next, tap "Wireless Devices", next, choose " Quick App"/"Fan Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep. 3.GoPro returns to the homepage manually. 4.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 5.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro7 Black	Bluetooth	√	√	√	×	×	×	√	×	×	01.90	1.50	1.How to active the Bluetooth for GoPro: Turn the camera on, please make sure the GoPro is recording mode, then turn the GoPro on, swipt down from homepage to find "Preferences", tap "Connections", click "Connect Device" next, tap "GoPro App". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. 3.After the connection is successful, we will hear the camera beep. 4.Single tap the global's shutter button. 5.GoPro camera back to the homepage after tap the back icon for "CONNECTION SUCCESSFUL" screen,"CONNECTION ATTEMPTED", please wait some time will "Retry to pair" disappeared. 6.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 7.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro7 White	Bluetooth	√	√	√	×	×	×	√	×	×	02.10	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on, swipt down from homepage to find "Preferences", tap "Connections", click "Connect to GoPro App". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep. 3.GoPro returns to the homepage manually. 4.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 5.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro8 Black	Bluetooth	√	√	√	×	×	×	√	×	×	02.01	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on ,please make sure the GoPro is taking picture mode,swipt down from homepage to find "Preferences", tap "Connections", click "Connect Device" next, choose " GoPro App"/"Remote" 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro9 Black	Bluetooth	√	√	√	×	×	×	√	×	×	01.72	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on, swipt down from homepage,then swipt left, click "Connections", tap "Connect Device", next, choose " Quick App"/"Fan Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro10	Bluetooth	√	√	√	×	×	×	√	×	×	01.46	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on, swipt down from homepage,then swipt left, click "Connections", tap "Connect Device", next, choose " Quick App"/"Fan Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro11	Bluetooth	√	√	√	×	×	×	√	×	×	01.12	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on, swipt down from homepage,then swipt left, click "Preferences", tap "Wireless connections",click "Connect Device" next, choose " Quick App"/"Fan Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro Max	Bluetooth	√	√	√	×	×	×	√	×	×	02.00	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on ,please make sure the GoPro is taking picture mode,swipt down from homepage to find "Preferences", tap "Connections", click "Connect Device", next, choose "Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.
GoPro	GoPro12	Bluetooth	√	√	√	×	×	×	√	×	×	01.10	1.50	1.How to active the Bluetooth for GoPro: Turn the GoPro on ,please make sure the GoPro is taking picture mode,swipt down from homepage to find "Connections", click "Connect Device", next, choose "Remote". 2.After turn the global on, swipt left to find "More", next, click "Bluetooth setting", tap the GoPro's bluetooth" GoPro####" and wait for connecting successfully. After the connection is successful, we will hear the camera beep, and the camera screen will prompt up "CONNECTION SUCCESSFUL". 3.For the global, please back to the homepage, and make sure the camera icon is upper in the upper left corner. 4.Single tap the shutter button on the gimbal to control start/stop recording,long press about 3 seconds to taking picture.

Remark:
√"Means Support this Function, "-" Means Do not Support."