Updating Time: 2022-03-18 Doc. Version: 1.0.3

FeiyuTech

Feiyu SCORP Pro Lens Compatibility List

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Sony	α9 α7 Ⅲ (A7M3) α7R Ⅲ α7S Ⅱ α7R Ⅲ α7R Ⅳ α7 Ⅲ (A7M3)	α9 126.9×95.6×63.0mm 588g α7M3 126.9×95.6×73.7mm 566g α7R Ⅲ 126.9×95.6×62.7mm 572g α7S Ⅱ 126.9×95.7×60.3mm 584g α7S Ⅲ 128.9 x 96.9 x 80.8mm 614g α7R2 126.9×95.7×60.3mm 582g α7R3 126.9×95.7×59.7mm 556g	E 10-18mm F4 OSS	Φ70mm×63.5mm 225g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 12-24mm F4 G	Φ87mm×113mm 565g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 16-35mm F2.8 GM	Φ89mm×122mm 680g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE16-35mm F/4 ZA OSS	Φ78mm×99mm 518g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 24-70 F2.8 GM	Φ87.6mm×135mm 886g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			Zeiss E 16-70 F4 OSS	Φ66.6mm×75mm 308g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			E PZ 18-105mm F4 G OSS	Φ78mm×110mm 427g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			E PZ 18-200mm F3.5-6.3 OSS LE	Φ93.2mm×99mm 649g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			E 4/24-105 G OSS	Φ83.4mm×113.3 mm 663g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 28-70mm f/3.5-5.6 OSS	Φ72.5mm×83mm 295g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 28mm F2	Φ66mm×60mm 200g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			Zeiss FE 35mm F2.8 ZA	Φ61.5mm×36.5mm 120g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			Sigma 30mm f/1.4 DC DN	Φ64.8mm×73.3mm 265g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			Sigma 35mm f1.4 DG HSM Art	Φ77mm×94mm 665g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 55mm F1.8	Φ64mm×77mm 281g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 50mm F2.8 MACRO	Φ71mm×77mm 236g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 85mm F1.4 GM	Φ89.5mm×107.5mm 820g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			Vario-Tessar FE 24-70mm F4 ZA OSS	Φ73mm×94.5mm 426g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	FX3	FX3: 77.8×129.7×84.5mm 640g	TAMRON 28-75mm F/2.8 Di III RXD	Φ73.0mm×117.8mm 550g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	✓	✓	
	A7R4	α7R4 129.0×97.0×81.0mm 699g	FE 24-240mm F3.5-6.3 OSS	Φ110×91mm 700g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Sony	α5100 α6000 α6100 α6300 α6400 α6500 α6600	α6300 120×66.9×48.0mm 361g α6400 120×67.0×60.0mm 399g α6500 120×66.9×53.3mm 410g	E 10-18mm F4 OSS	Φ70mm×63.5mm 225g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 12-24mm F4 G	Φ87mm×113mm 565g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 16-35mm F2.8 GM	Φ89mm×122mm 680g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE16-35mm F/4 ZA OSS	Φ78mm×99mm 518g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 24-70 F2.8 GM	Φ87.6mm×135mm 886g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			Zeiss E 16-70 F4 OSS	Φ66.6mm×75mm 308g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			E PZ 18-105mm F4 G OSS	Φ78mm×110mm 427g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			E PZ 18-200mm F3.5-6.3 OSS LE	Φ93.2mm×99mm 649g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			E 4/24-105 G OSS	Φ83.4mm×113.3 mm 663g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 28-70mm f/3.5-5.6 OSS	Φ72.5mm×83mm 295g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 28mm F2	Φ66mm×60mm 200g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			Zeiss FE 35mm F2.8 ZA	Φ61.5mm×36.5mm 120g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			Sigma 30mm f/1.4 DC DN	Φ64.8mm×73.3mm 265g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			Sigma 35mm f1.4 DG HSM Art	Φ77mm×94mm 665g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			FE 55mm F1.8	Φ64mm×77mm 281g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 50mm F2.8 MACRO	Φ71mm×77mm 236g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 28-70mm f/3.5-5.6 OSS	Φ72.5mm×83mm 295g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			FE 85mm F1.4 GM	Φ89.5mm×107.5mm 820g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Panasonic	DC-GH5GGK-K DC-GH5 DC-G90K-K DMC-GH4GK	GH5S 138.5×98.1×87.4mm 660g GH5 138.5×98.1×87.4mm 725g G9 136.9×97.3×91.5mm 658g GH4 93.4×83.9×132.9mm 560g	LEICA DG SUMMILUX 15mm f/1.7 ASPH	Φ58×36×46mm 115.00g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			LEICA DG SUMMILUX 25mm f/1.4 ASPH	Φ77.7mm×75mm 510g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			LEICA DG MACRO-ELMAR f/2.8 OIS	Φ63mm×62.5mm 225g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Φ73.4mm×88mm 315g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS	Φ66mm×86mm 320g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			LUMIX G X Vario 12-35mm F/2.8 II ASPH POWER OIS (H-HS12035K)(PL)	Φ68mm×74mm 305g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			M.ZUIKO DIGITAL ED 12mm f/2.0	Φ56mm×43mm 130g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			LUMIX G 14-140mm f/4-5.8 OIS	Φ70mm×84mm 460g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	S1H	S1 151.0×114.2×110.4mm 1164g	LUMIX S PRO 24-70mm f/2.8	Φ90.9×140mm 935g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	S5	S5 132.6×97.1×81.9mm 714g	LUMIX S 24-105mm F4	Φ84mm×118mm 680g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Nikon	Z6 Z6 Ⅱ Z7 Z7 Ⅱ	Z6 134×100.5×67.5mm 675g Z6 Ⅱ 134×100.5×69.5mm 615g Z7 134×100.5×67.5mm 675g Z7 Ⅱ 134×100.5×67.5mm 705g	NIKKOR Z 35mm f/1.8	Φ73mm×56mm 370g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			18-140mm F/3.5-5.6G ED VR	Φ78mm×79mm 490g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			NIKKOR Z 50mm f/1.8 S	Φ76mm×56.5mm 415g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			NIKKOR Z 24-70mm f/4 S	Φ77.5mm×85.5mm 500g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			NIKKOR Z 14-30mm f/4 S	Φ85mm×91mm 485g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	D7500	D7500 135.5×104×72.5mm 720g	18-140mm F/3.5-5.6G ED VR	Φ78mm×79mm 490g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	Z50	Z50 126.5×92.5×60mm 450g	NIKKOR Z DX 16-50mm F/3.5-6.3 VR	Φ70mm×32mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	×	×	The lens is too short to install a Focus motor
	Zfc	Zfc 134.5×93.5×43.5mm 445g	NIKKOR Z DX 16-50mm F/3.5-6.3 VR	Φ70mm×32mm 135g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Canon	EOS R EOS RP EOS R6	EOS R 135.8×98.3×84.4mm 660g EOS RP 132.5×85×70mm 485g EOS R6 138.4×97.5×88.4mm 598g	RF 35mm F1.8 MACRO IS STM	Φ74.4mm×62.8mm 305g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm×102mm 595g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 50mm f/1.4 DG HSM Art	Φ85mm×106mm 815g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 17-40mm f/4L USM	Φ83.5mm×86.8mm 475g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 50mm F1.2L USM	Φ89.8mm×108mm 950g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 28-70mm F2L USM	Φ103.8mm×139.8mm 1430g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 24-105mm F4L IS USM	Φ83.5mm×107.3mm 670g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			RF 15-35mm F2.8 L IS USM	Φ88.5mm×126.8mm 840g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 80D	EOS 80D 139.1×105.2×78.5mm 730g	EF-S 18-200mm F/3.5-5.6 IS	Φ78.6mm×102mm 595g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 6D Mark Ⅱ	6D Mark II 144×110.5×74.8mm 765g	EF 24-70mm f/4L IS USM	Φ83.4mm×93mm 600g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 6D	EOS 6D 144.5×110.5×71.2mm 750g	16-35mm f/2.8L II USM	Φ88.5mm×111.6mm 635g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm×102mm 595g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF 24-105mm f/4L IS USM	Φ83.5mm×107mm 670g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 200D Ⅱ	EOS 200D Ⅱ 122.4×92.6×69.8mm 456g	EF-S18-55mm f/4-5.6 IS STM	Φ66.5mm×61.8mm 215g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 5D Mark Ⅳ	5D Mark Ⅳ 150.7×116.4×75.9mm 890g	EF 24-105mm f/4L IS USM	Φ83.5mm×107mm 670g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF 24-105mm f/4L IS USM	Φ83.5mm×107mm 670g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 5D Mark Ⅲ EOS 5DS R	5D Mark III 152×116.4×76.4mm 950g 5DS R 152×116.4×76.4mm 930g	EF 24-105 mm f/4L IS II USM	Φ88.5mm ×127.5mm 795g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			EF 24-70mm f/2.8L II USM	Φ88.5mm×113mm 805g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			16-35mm f/2.8L II USM	Φ88.5mm×111.6mm 635g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 70D	EOS 70D 139×104.3×78.5mm 755g	16-35mm f/2.8L II USM	Φ88.5mm×111.6mm 635g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 77D	EOS 77D 131×99.9×76.2mm 540g	EF 24-70mm f/4L IS USM	Φ83.4mm×93mm 600g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	EOS M50	M50 116.3×88.1×58.7mm 390g	EF-M 15-45mm F3.5-6.3 IS	Φ60.9mm×44.5mm 130g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
	EOS 850D	EOS 850D 131×102.6×76.2mm 515g	EF-S 18-55mm f/4-5.6 IS STM	Φ66.5mm×61.8mm 215g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
	EOS-1D X Mark Ⅲ	1D X Mark III 158×167.6×82.6mm 1250g	CANON EF 70-200mm f/2.8L IS III USM	Φ88.8×199mm 1480g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Fujifilm	X-T2 X-T3	X-T2 133×92×48mm 457g X-T3 132.5×92.8×58.8mm 539g	XF 16mm f/1.4 R WR	Φ73mm×73mm 375g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 23mm f/1.4 R	Φ72mm×63mm 300g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 35mm f/1.4	Φ65mm×54.9mm 187g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			XF 10-24mm f/4.0 R OIS	Φ78mm×87mm 410g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 16-55mm f/2.8 R LM WR	Φ83.3mm x 106.0mm 655g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-55mm f/2.8-4 R OIS	Φ65mm×70.4mm 310g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm×99mm 490g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
	X-H1	X-H1 139.8×97.3×85.5mm 673g	XF 16mm f/1.4 R WR	Φ73mm×73mm 375g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 23mm f/1.4 R	Φ72mm×63mm 300g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 35mm f/1.4	Φ65mm×54.9mm 187g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			XF 10-24mm f/4.0 R OIS	Φ78mm×87mm 410g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 16-55mm f/2.8 R LM WR	Φ83.3mm x 106.0mm 655g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-55mm f/2.8-4 R OIS	Φ65mm×70.4mm 310g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm×99mm 490g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm×65.2mm 135g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
	X-S10	X-S10 126×85.1×65.4mm 465g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm×65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	✓	✓	
	X-A5	X-A5 116.9×67.7×40.4mm 361g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm×65.2mm 135g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	✓	✓	

Brand	Camera Model	Camera Size	Lens Model	Lens size & weight	Mounting status	Balance adjustment (install horizontally)		Balance adjustment (install vertical)		Installation Remark
						Short End	Long End	Short End	Long End	
Fujifilm	X-T20 X-T30	X-T20 118.4×82.8×41.4mm 383g X-T30 118.4×82.8×46.8mm 383g	XF 16mm f/1.4 R WR	Φ73mm×73mm 375g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 23mm f/1.4 R	Φ72mm×63mm 300g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 35mm f/1.4	Φ65mm×54.9mm 187g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			XF 10-24mm f/4.0 R OIS	Φ78mm×87mm 410g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XC 16-50mm f/3.5-5.6 OIS	Φ62.6mm×65.2mm 195g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
			XF 16-55mm 1:2.8 R LM WR	Φ83.3mm x 106.0mm 655g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-55mm 1:2.8-4 R OIS	Φ65mm×70.4mm 310g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm×99mm 490g	Camera + Lens	✓	✓	✓	✓	
					Focus motor + Camera	✓	✓	✓	✓	
			XC 15-45mm 1:3.5-5.6 OIS PZ	Φ62.6mm×65.2mm 135g	Camera + Lens	✓	✓	✓	✓	camera riser is required to help balancing the gimbal
					Focus motor + Camera	✓	✓	✓	✓	
SIGMA	fp	fp 112.6×69.9×45.3mm 370g	Panasonic LUMIX S PRO 50mm F1.4	Φ90mm×130mm 955g	Camera + Lens	✓	✓	✓	✓	Camera Riser Required
					Focus motor + Camera	✓	✓	✓	✓	
BMPCC	6K	BMPCC 177.8×101.4×96.52mm 898g	CANON EF 16-35mm F2.8L II USM	Φ88.5mm×111.6mm 640g	Camera + Lens+ cage+battery	✓	✓	×	×	
						✓	✓	×	×	

Notice:
1. "✓" Means Support this function, "×" Means Do not Support;